## Pioneer sound.vision.soul

Service Manual **TOYOTA** 

ORDER NO. CRT3277

SCION AUDIO SYSTEM 6-DISC CD CHANGER

# DEH-MG8147zT/xu/uc



VEHICLE	DESTINATION	PRODUCED AFTER	TOYOTA PART No.	ID No.	PIONEER MODEL No.
xA, xB, tC	U.S.A., CANADA	July 2004	86120-0W110	T1805	DEH-MG8147ZT/XU/UC

This service manual should be used together with the manual(s) listed below. For the parts numbers, adjustments, etc. which are not shown in this manual, refer to the following manual(s).

Model No.	Order No.	Mech.Module	Remarks
DEH-MG8137ZT/UC	CRT3063		
CX-951	CRT2872	G2	CD Mech. Module:Circuit Description, Mech. Description, Disassembly

## **EXPLODED VIEWS AND PARTS LIST**

## PACKING(Page 5)

PACKING SECTION PARTS LIST


Mark	No.	Description	DEH-MG8137ZT/UC	DEH-MG8147ZT/XU/UC
	7	Carton	CHG5059	CHG5145
	8	Contain Box	CHL5059	CHL5262
	9	Protector	CHP2697	CHP2745
	10	Protector	CHP2698	CHP2746
	11	Owner's Manual	CRB1827	CRB1934

## EXTERIOR(Page 6) ● EXTERIOR SECTION PARTS LIST

Mark	No.	Description	DEH-MG8137ZT/UC	DEH-MG8147ZT/XU/UC
	9	Main Unit	CWM8739	CWM9480
	48	Keyboard Unit	CWM8740	CWM9482
	57	Grille Unit	CXC1324	CXC3125
	68	Control Unit(G2MP3T)	CWX2787	CWX3055
	76	CD Mechanism Module(G2MP3T)	Not used	CXK7141

3

2




Ε

DEH-MG8147ZT/XU/UC

# ELECTRICAL PARTS LIST(Page 44) Main Unit

Circuit Symbol and No.	Part Name	DEH-MG8137ZT/UC	DEH-MG8147ZT/XU/UC
IC701	IC	PD5860A	PEG004A
CG501	Surge Protector	DSP-201M-A21F	DSP-201M-S00B
R764		RS1/16S102J	RS1/16S152J
R765		RS1/16S102J	RS1/16S152J
C496		Not used	CKSQYB473K50



### **Keyboard Unit**

Circuit Symbol and No.	Part Name	DEH-MG8137ZT/UC	DEH-MG8147ZT/XU/UC
S901-S906	Switch	CSG1154	CSG1169
S907,S908	Switch	CSG1154	CSG1171
S909-S916	Switch	CSG1154	CSG1169
S917,S918	Switch	CSG1154	CSG1171
S919-S924	Switch	CSG1154	CSG1169

### Control Unit (G2TMP3T)

Circuit Symbol and No.	Part Name	DEH-MG8137ZT/UC	DEH-MG8147ZT/XU/UC	
IC701	IC	PE5371A	PE5442A	

8

В

С

D

Е